Hours of use	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1
Engine Filter and Oil																					
Transmission fluid	<b>~</b>			<b>~</b>				<b>~</b>				<b>✓</b>				<b>~</b>				<b>~</b>	
Hyd. Oil Filter	<b>~</b>					<b>~</b>						<b>~</b>						<b>~</b>			
Front Diff./Wheel Case Oil	<b>~</b>					<b>~</b>						<b>~</b>						<b>~</b>			
Steering Gear Case Oil						~						~						<b>~</b>			
Battery Electrolyte Level					<b>~</b>							<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>			
Grease All Zerks		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>			
Clutch Pedal Play		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>✓</b>		<b>~</b>		<b>~</b>		<b>~</b>			
Brake Pedal Play		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>			
Toe-In Check		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>		<b>~</b>			
Front Axle Front- Back Play				~				~				~				~					
Clean Air Cleaner Element		<b>~</b>		<b>~</b>		~		<b>~</b>		<b>~</b>		~		~		<b>~</b>		<b>~</b>			
Radiator Screen and Coolant Levels	<b>~</b>	<b>~</b>	<b>~</b>	<b>~</b>	~	~	~	<b>~</b>	~	<b>~</b>	~	~	~	~	~	~	~	~	~	~	
Fan Belt Tension		<b>~</b>				<b>~</b>			<b>~</b>			<b>~</b>			<b>~</b>			<b>~</b>			
Fuel Filter Element						<b>~</b>						<b>~</b>					<b>~</b>				
Valve Clearance																<b>~</b>					

Tire Pressure	~	~	<b>~</b>	<b>~</b>	<b>~</b>	~	<b>~</b>	~	<b>~</b>	<b>~</b>												
Tire Wear	~	<b>~</b>																				
Safety Switches	~	<b>~</b>	~	<b>~</b>	<b>~</b>																	
Replace Anti- Freeze in the Cooling System																			<b>~</b>		~	<b>~</b>
Replace Air Cleaner																					<b>~</b>	<b>~</b>
Check Power Steering Hoses																					<b>~</b>	<b>~</b>
Check Fuel Lines																					<b>~</b>	<b>~</b>
Check Radiator Hoses																					<b>~</b>	<b>~</b>